



S&W READY MIX CONCRETE COMPANY	April
CORPORATE ENVIRONMENTAL / SAFETY PROGRAM	
Spill Kit Training - MONTHLY TRAINING TOPIC	

Spill kits are required on all S&W Ready Mix Concrete trucks to contain any petroleum-based (diesel fuel, motor oil, hydraulic oil, etc.) spill or leak. The kit will include a 6' x 10' piece of plastic, oil dry and 4 absorbent pads.

If a spill occurs while operating a concrete truck the most important thing to remember is to try and contain the spill as much as possible. A piece of plastic has been provided to serve as a base and to keep the product from contaminating and leaching into the soil. When a spill or leak occurs simply spread the plastic out, place the oil dry on top of the plastic and if possible, place the bucket directly under the leak. Also, the plastic makes it much easier to clean up the spilled material after the repairs have been made. If the spill is too large to be contained with the kit that has been provided, try and prevent the material from leaving the immediate area until help can arrive.

Should the material run-off into a stream or ditch, if possible, create a temporary dike or dam to try and stop the flow. The absorbent pads can then be utilized to clean up any contaminants.

No matter how big or how small the spill may be it is everyone's responsibility to re-act and perform in an environmentally friendly manner.

